




Quick Installation Guide

Phoenix Inverter 24V 48V 5000VA 230Vac

www.victronenergy.com











Fuse (not included)


For fuse values: refer to the user manual




















10